

# ParcelHome 3 – Free standing installation preparation.

---

## Caution:

Insertion surface: This is for soil surfaces only, please send an email at: [pilot@parcelhome.com](mailto:pilot@parcelhome.com) for other types of grounds, as we may have solutions. We need to insert a pin on a depth of 40 cm.



## Principle

The ParcelHome 3 will be resting on a foot which will be resting on an anchor. Our technician will insert the anchor into the soil and then attach the foot and the ParcelHome 3 unit above it. The technician will determine the adequate tools for the soil you use.



## Requirements

- 1) A foot we have provided to you
- 2) Your smartphone

## Step 1: Choose where to place your box

- 1) Accessibility:  
The box should typically be visible from the street so the delivery people can find it quickly.
- 2) Light  
The ParcelHome 3 is charged by solar power. Only the top sheet needs to receive light for the unit to work. The box does not require direct sunlight, but should be placed in an area where it can directly see a significant amount of sky – if you are looking from where the box will be, 110cm above the ground, you should have at least 25% of sky or sun reflection on light-coloured buildings. If no such spot is available, the box will likely work, but please choose one of the best-lit areas of your property. As a rule of thumb, areas where plants grow well work.
- 3) Areas to avoid:
  - Areas where they may obstruct passage on the street
  - Indoor or roofed areas (e.g. inside a shed or an open shed)
  - Places which are often damp
  - Places where moss grows (close to the level of the top sheet of the box)
- 4) Size and surface type
  - You need a patch of **dense soil** where we can dig. Dense soil is required for us to insert the pin. The pin will not work in soft and recently Make sure that there are no pipes or electric cables.
  - Concrete or stone installation also

## Step 2: Mark the place – to do a day or two before the target installation date

- 1) Place the foot
- 2) Check that there are no wires or pipes in the area for the box. We will dig up to 40cm.

## Step 3: Take a picture and send us your agreement to the disclaimer

- 1) Send us a picture at [pilot@parcelhome.com](mailto:pilot@parcelhome.com)

- 2) Agree to the disclaimer and mail us your agreement
- 3) Leave the foot in place